

D10 – Bathroom suite to be removed.

D11 – Roof felt over parapet to be removed

D12 – Brown plaster to be removed adjacent to crack.
D13 – RWP to be carefully removed and stored.

RIBA Stage

1:50@A1 STAGE 3

20-020 P121 -

Richmond, North Yorkshire info@cellardoorarchitecture.co.uk 01748 825 669

Cellar Door Architecture accepts no liability for any such alterations or additions to or discrepancies arising out of changes to such background information which occur after it is issued by Cellar Door Architecture.