



- 1 Standard scaffold poles
- 2 Uprights to be driven into the ground
- 3 Panels secured to uprights with wire ties and where necessary standard scaffold clamps
- 4 Weldmesh wired to the uprights and horizontals
- 5 Standard clamps
- 6 Wire twisted and secured on inside face of fencing to avoid easy dismantling
- 7 Ground level
- 8 Approx. 0.6 m driven into the ground



These drawings are for DESIGN purposes only. 2DB are not liable for unforeseen problems in build. Please DO NOT Scale this drawing, dimensions must be checked on site before building works commence & any discrepancies reported.  
Bill Kane 07971926112

<b>Tree Protection Zone</b>				
9 Cedar Close RAF Lakenheath IP279QN				
Nathaniel Cohn				
No:	Revision:	Date:	Date:	27-09-2021
			Scale:	1-200
			Drawn By:	WK
			Drawing No:	056
			Paper Size:	A1