

Schedule of works

Removing everything that's there (old liner, closure sheet, etc)
Fabricating a new closure framework with sheet steel panels
Installation of a twin wall insulated flue system
Supply and seat a new chimney pot to get the system to terminate at the right height
HETAS registration of the new installation