1	Α	В	С	D
SC	CHEDULE OF	1-3 The Row, Donnington GL56 OPE		
1 w	VORKS:			
2				
3 P	hase 1 - The exist	ing house September 2022 - July 2023		
IN	NTERNAL	No.1 Ground Floor	No.1 Ground Floor	No.1 Ground Floor
	VORKS			
5		Snug	Single storey extension	Staircase
6				
D€			,	Carefully remove two inch plaster board stud work
i		NB Not below footing level.		making up staircase wall (approx. 1.25sqm) Please see
i				photo enclosed with letter - replace with single glase
i				11mm laminated clear glass fenustration in crittel style
i				frame.
i				
i				
7				
Ce	eilings	Retain exisitng lathe and plaster ceiling. Light sand	New extension - pine ceiling joists, with 2 layers	Retain Existing plasterboard ceiling, sand to key decorate
i				with two top coats white emulsion
i		& adhesive, Decorate with one mist coat and two top		
8		coats.	skim finish, decorate	
	lew Windows	N/A	New hardwood windows as per detail drawings,	N/Δ
'''	iew wiiiaows	14/14	decorated as per approved colour.	17/0
9			decorated as per approved colour.	
Ex	xisting Windows	Repair, restore. Paint finish	Repair, restore. Paint finish	Repair, restore. Paint finish
10	_	•		7
In	nternal Doors	Retain original door and door funiture, sand to a key	_	Retain original door and door funiture, sand to a key and
		and redecorate.	key and redecorate.	redecorate.
11				
l lw		Spread new 3 coat lime render to fine finish.	Spread new 3 coat lime render to fine finish.	Lower part of staircase - carefully remove traingular
		Insulating lime to external walls.	_	boxing around kite wind (1980's stud wall and 9mm
				plasterboard) close the opening with crittal style
				toughened glass fenustration.
12				

	А	В	С	D
	Walls Timber	See Internal Works No.3. Ground Floor Rear Annex		
13				
14	INTERNAL WORKS	No.1 Ground Floor	No.1 Ground Floor	No.1 Ground Floor
15		Snug	Single storey extension	Staircase to Snug
16	Floors	New conrete slab, dpm, insulated	New insulated oversight to wood finishes	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists at 150c/c - relay original pine floors ready for carpet
17	Electrics	See plan		
- '	Plumbing	UFH	UFH	N/A
18				
	Fireplace and Chimneys	restore fireplace, re install existing install wood burner, check flues are clear and liner condition, repair flues		
19				
20				
21				
22				
23				
24 25				
26				
27				
28				
29				
30				
31				
32				

	А	В	С	D
33		<u>Б</u>	<u>C</u>	
34				
_				
35				
36				
27	EXTERNAL		EXTERNAL WORKS	
37	WORKS		lanca a sa	
38	Guttering	New guttering cast iron half round	All Windows and Doors (new)	Please see 1:5 Scale plans painted Farrow & Ball exterior
30	01.			eggshell - Bone
39	Chimneys &	Inspect chimneys nd report. Repair leaking		
33	Flaunching	flaunchings with sand cement to match.		
	New roofs	Please see photo attached in Letter - Sample	Phase 2 - The New Kitchen Extension	
		Cotswold Plain Tile. Proposed Redland Concrete	September 2023 - July 2024	
		Cotswold Plain Roof Tile to match existing concrete		
		cotswold colour Plain Roof Tiles. Roof in new		
		extension ensuite of glass and tin. See details		
		drawings. The Kitchen Extension please see Photo		
40		attached in letter - Sample tin roof nearby property.		
	Walls and	Demolish as per planning drawings, re-use stone,	Phase 3 - The New Garage, pool and buildings	
41	Parapet	import new matching sawn tumbled stone.	September 2024 - July 2025	
	All Windows and	Repair, restore. Paint finish Farrow & Ball exterior		
	Doors (existing)	eggshell - Bone. See photo painted door and		
42		window.		
1	All Windows and	Please see 1:5 Scale plans painted Farrow & Ball		
43	Doors (new)	exterior eggshell - Bone		
	Gardens and	please see attached site plan based on the tree		
1.	Landscape	survey commissioned previously and attached again.		
44				

	E	F	G	Н
1				
2				
3				
	INTERNAL	No.1 First Floor	No.1 First Floor	No.1 First Floor
4	WORKS			<u>.</u>
5 6		Bedroom 1	Bedroom 2	Bathroom
	Demolitions	N/A	check for asbestos, - remove rear extension cat	install new oak lintel to make new opening in front wall, install 6x2
7	Demondons		slide roof and retain tiles for reinstallation, rear and side walls making up the 1980's dorma extension in room - support floors and remaining windows - carefully remove cinder block, separate stone for re-use prepare original walls ready to blend in site recovered and locally sourced matching new stone.	timber brace, ready for new hardwood casement window
8	Ceilings	Create Warm Roof, fill rafter depth with Hemp Therma Fleece, overboard with Lafarge insulated board to create warm roof, skim, decorate	Create Warm Roof, fill rafter depth with Hemp Therma Fleece, overboard with Lafarge insulated board to create warm roof, skim, decorate	Create Warm Roof, fill joist depth to existing felt Hemp Hemp Therma Fleeceoverboard with Lafarge insulated board to create warm roof, skim, decorate
9	New Windows	New hardwood windows as per detail drawings, decorated as per approved colour.	N/A	New hardwood windows as per detail drawings, decorated as per conditions colour.
10	Existing Windows	Repair, restore. Paint finish	Repair, restore. Paint finish	Repair, restore. Paint finish
11	Internal Doors		Retain original door and door funiture, sand to a key and redecorate.	Retain original door and door funiture, sand to a key and redecorate.
12	Walls		Remove all blown plaster and render (existing is mixed bonding, sand cement and lime, bonding where extensively used is wet and original plaster is blown). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.

	E	F	G	Н
13				
1.4		No.1 First Floor	No.1 First Floor	No.1 First Floor
14 15	WORKS	Bedroom 1	Bedroom 2	Bathroom
16	Floors		Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end -	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side, fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists at 150c/c, install damp proof system and underfloor heating insulation mat and tile
	Electrics		See plan	See plan to include elec UFH
17	5 1 11	- II .		
18	Plumbing	Radiator	Radiator	Shower, loo, basin, towel rad
	Fireplace and Chimneys			
19				
20				
21 22				
23				
24				
25				
26				
27				
28 29				
30				
31				
32				

	Е	F	G	Н
33				
34				
35				
36				
37		I		1
38				
39				
40				
41				
42				
43				
44				

	I	J	K	L
1				
2				
3				
4	INTERNAL WORKS	No.2 Ground Floor	No. 2 Ground Floor	No.2 First Floor
5		Entrance hall & Aga Room	Rear Utility Room	Bedroom 3
6				
7	Demolitions	Prop inglenook working area, carefully remove the registration plate, remove steel I beam and replace with seasoned local oak beam, dry pack and sand lime pointed in to finish, line flue, repalce registration plate, install wood burner.	remove lean to roof, nib and extenal wall.	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.
8	Ceilings	Ceiling to remain, make good, prep and decorate	New 1hr Fire rated ceiling fixed to new treated first floor joists	Wire brush and decorate in lime wash
9	New Windows	N/A	New interanl doorway through - See detail drawings	N/A
10	Existing Windows	Repair, restore. Paint finish	Repair, restore. Paint finish	Repair, restore. Paint finish
11	Internal Doors	N/A	Retain original door and door funiture, sand to a key and redecorate.	Retain original door and door funiture, sand to a key and redecorate.
	Walls			Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.

	I	J	K	L
13				
14	INTERNAL WORKS	No.2 Ground Floor	No. 2 Ground Floor	No.2 First Floor
15		Entrance hall & Aga Room	Rear Utility Room	Bedroom 3
16	Floors	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - remove broken joists and re install new - install 25mm ply screwed to joists at 150c/c - relay original pine floors - sand and stain with three coats bono floor top coat	New hardwood flooring	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists at 150c/c - relay original pine floors ready for carpet
"	Electrics			
17				
18	Plumbing	make good screed and install insulated UFH wet system in	UFH in screed	Radiator
10	Fireplace and	50mm screed restore ingelnook using existing stone, replace steel I-beam		
	Chimneys	and brick in fill above with one peice of locally sourced and		
	•	milled seasoned sawn oak beeam, check flues are clear and		
19		liner condition, repair flues, , reinstate fireplace iron fire		
20		hack and onen fire grate		
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				

	I	J	K	L
33				
34				
35				
36				
37				
38				
39				
40				
40				
41				
42				
43				
44				

	М	N	0
1			
2			
3			
4	INTERNAL WORKS	No.2 First Floor	No.2 First Floor
5		Bathroom	Staircase and hall
6			
	Demolitions	Prop structures where required and demolish side wall nib, lift floors and reset joists to new FFL	Repair floor joists and strengthen from below with brother joists in locally milled seasoned oak
7	0 11		
8	Ceilings	Ceiling to remain, make good, prep and decorate	Ceiling to remain, make good, prep and decorate
9	New Windows	N/A	New hardwood windows as per detail drawings, decorated as per conditions colour.
10	Existing Windows	Repair, restore. Paint finish	N/A
11	Internal Doors	Retain original door and door funiture, sand to a key and redecorate.	N/A
	Walls	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.
12			

	М	N	0
13			
14	INTERNAL WORKS	No.2 First Floor	No.2 First Floor
15		Shower Room	Staircase and hall
16	Floors	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side, fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists at 150c/c, install damp proof system and underfloor heating insulation mat and tile	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists at 150c/c - relay original pine floors ready for carpet
17	Electrics	Elec UFH	See plan
18	Plumbing	Shower, Toilet, Basin, Towel Rad	N/A
	Fireplace and Chimneys		
19			
20			
21 22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			

	М	N	0
33			
34			
35			
36			
37		1	
38			
39			
40			
41			
42			
43			
44			

	Р	Q	R
1			
2			
3			
	No.2 Second Floor	INTERNAL WORKS	No.2 Second Floor
4			
5	Dressing		Ensuite
6	Remove plasterboard ceilings and rockwool and	Demolitions	Remove plasterboard and rockwool and leave roof structure to
	leave roof structure to air ready for warm roof	Demontions	air ready for warm roof installation
	installation, form opening through to bedroom 5.		an ready for warm roof installation
	1970's Lathe and plaster wall - make good opening		
	up works with oak lathe and lime plaster, remove		
	staircase and make good opening to match exisitng		
	bedroom floor and ceiling plasterboard levels below.		
7			
	Re-install upgraded roof insulation using Hempwool	Ceilings	Re-install upgraded roof insulation using Hempwool to fill void,
	to fill void, overboard with Lafarge insulated board		overboard with Lafarge insulated board to create warm roof,
	to create warm roof, skim, decorate		skim, decorate
8			
	N/A	New Windows	Window as per pp, decorated. See detail plans
9			
9	Repair, restore. Paint finish	Existing Windows	Repair, restore. Paint finish
10	Repair, restore. Faint initial	Existing windows	nepuit, restore. I unit illisii
	New, handmade locally, ledge and brace door to	Internal Doors	N/A
11	dressing room		
11	Remove all blown plaster and render (existing is	Walls	Remove all blown plaster and render (existing is mixed
	mixed bonding, sand cement and lime). Spread new	vvalis	bonding, sand cement and lime). Spread new 3 coat lime
	3 coat lime render to fine finish. Insulating lime to		render to fine finish. Insulating lime to external walls.
	external walls.		
12			
12			

	Р	Q	R
13			
-	No.2 Second Floor	INTERNAL WORKS	No.2 Second Floor
14			
	Dressing		Ensuite
	,	Floors	Carefully lift floorboards and check floor joists. Relay loose
	Relay loose ready for electrician and plumber first fix		ready for electrician and plumber first fix - support
	- support failed joists with new joist along side fixed		failed joists with new joist along side fixed and bolted 350c/c's
	and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed		to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists at 150c/c - relay original
	to joists at 150c/c - relay original pine floors ready		pine floors ready for carpet
	for carpet		pline noors ready for carpet
10	·		
17	See plan	Electrics	Elec UFH
	Radiator	Plumbing	Bath, Shower, Toilet, Basin, Towel Rad
18			
		Fireplace and	
		Chimneys	
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			

	Р	Q	R
33			
34			
35			
36			
37		I	
38			
39			
40			
41			
42			
43			
44			

	S	Т	U	V
1				
3				
	No.2 Second Floor	No.3 Ground Floor	INTERNAL WORKS	No.3 Ground Floor
4				
-	Staircase	Front Door and lobby	I	Sitting Room
6				
	Remove all blown plaster and render (existing is mixed		Demolitions	remove plasterboard boxing of fire place , LIFT
	bonding, sand cement and lime). There has also been a			floor coverings where necessary and dispose
	long term leak from failed external flaunching, Spread new 3 coat lime render to fine finish. Insulating lime to			
	external walls.			
	external wans.			
7				
-	overboard with Lafarge insulated board to create warm	Replace existing plasterboard with new fire	Ceilings	Ceiling to remain, make good, prep and
	roof, skim, decorate, replaster wealls in Lime render	rated board, skim, decorate		decorate
	and fine skim finish, decorate lime wash			
8				
	N/A	N/A	New Windows	N/A
				.,
9				
10	N/A	N/A	Existing Windows	Repair, restore. Paint finish
10	Retain original door and door funiture, sand to a key	Retain original door and door funiture, sand to	Internal Doors	Retain original door and door funiture, sand to
	and redecorate.	a key and redecorate.	internal boots	a key and redecorate.
11		2.12, 2.12, 2.22, 2.12,		
		Remove all blown plaster and render (existing	Walls	Remove all blown plaster and render (existing
	bonding, sand cement and lime). Spread new 3 coat	is mixed bonding, sand cement and lime).		is mixed bonding, sand cement and lime).
	lime render to fine finish. Insulating lime to external	Spread new 3 coat lime render to fine finish.		Spread new 3 coat lime render to fine finish.
	walls.	Insulating lime to external walls.		Insulating lime to external walls.
12				

	S	Т	U	V
			Walls Timber	
13				
	No.2 Second Floor	No.3 Ground Floor	INTERNAL WORKS	No.3 Ground Floor
14				
15		Front Door and lobby Carefully lift red floor tiles install damp proof	Floors	Sitting Room Lift carpet floor coverings install damp proof
		system, underfloor heating insulation mat,	FIOOIS	system, underfloor heating insulation mat,
		plywood layer and re tile		plywood layer ready for carpet.
	and bolted 350c/c's to joists, bedded into stone walls to	j		
	support at each end - install 25mm ply screwed to			
	joists at 150c/c - relay original pine floors ready for			
16	carpet			
			Electrics	
17	A1/A	UFH	Diametria -	lueu.
18	N/A	UFH	Plumbing	UFH
			Chimneys	restore firepalce, check flue with new locally
				sourced seasoned sawn oak beeam, restore
				fireplace, check flues are clear and liner
19				condition, repair flues, install iron fire back and
20				AND ITS OF STE
21				
22				
23				
24				
25				
26				
27 28				
29				
30				
31				
32				
52				

	S	Т	U	V
33				
34 35				
35				
36				
37			ı	
38				
39				
40				
41				
42				
43				
44				

	W	X	Υ
1			
2			
3			
4	No.3 Ground Floor	No. 3 First Floor	INTERNAL WORKS
5	Rear Annex	Corridor	
6			
	Break through doorway and make good. Adjust external wall to accommodate new window arrangement as per pp LIFT floor coverings and tiles where necessary and dispose, Salvage stone for re use in building on site/	Remove plasterboard and rockwool and leave roof structure to air ready for warm roof installation	Demolitions
7			
	Ceiling to remain, make good, prep and decorate	Re-install upgraded roof insulation using Hempwool to fill void, overboard with Lafarge insulated board to create warm roof, skim, decorate	Ceilings
8			
9	New Hardwood Window as per pp, decorated. See detail plans	New Hardwood Window as per pp, decorated. See detail plans	New Windows
10	N/A	N/A	Existing Windows
11	Retain original door and door funiture, sand to a key and redecorate.	See details drawings	Internal Doors
	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.	Walls
12			

14 15 Re Ca mis	Il opening with timber frame and external oak ertical wall panelling. Leave to colour aturally. o.3 Ground Floor ear Annex arefully lift tiles, underfloor heating insulation at and re tile	No. 3 First Floor Corridor	INTERNAL WORKS Floors
13 na No 14 15 Re ma	ear Annex arefully lift tiles, underfloor heating insulation	Corridor Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	
14 15 Re Ca mis	o.3 Ground Floor ear Annex arefully lift tiles, underfloor heating insulation	Corridor Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	
14 Re Ca max 16 Re 17 an Ra	ear Annex arefully lift tiles, underfloor heating insulation	Corridor Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	
15 Re man	arefully lift tiles, underfloor heating insulation	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	Floors
16 Re 17 an Ra	arefully lift tiles, underfloor heating insulation	Carefully lift floorboards and check floor joists. Relay loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	Floors
16 Re 17 an Ra		loose ready for electrician and plumber first fix - support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	110013
16 Re 17 an	ac and re the	- support failed joists with new joist along side fixed and bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	
17 an		bolted 350c/c's to joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists	
17 an		support at each end - install 25mm ply screwed to joists	ļ
17 an		1	1
17 an		Tal 150C/C - relay original bine 1100rs ready for carbel	
17 an		and any of the second s	
17 _{an}	eplace window and door with timber panel		Electrics
Ra	nd window light.		Electrics
1 4 4 1	adiator	N/A	Plumbing
18			
			Chimneys
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32		 	·

	W	Х	Υ
33			
34			
35			
36			
37		ı	
38			
39			
40			
41			
42			
43			
44			

	Z	AA	AB
1			
2			
3			
	No. 3 First Floor	No.3 Second Floor	
5	En-suite	Bedroom 5	
6	Eii-suite		
	Remove 1980 extension ceiling ready for new installation.	Remove staircase and make good ceiling to match existing.Remove plasterboard and rockwool and leave roof structure to air ready for warm roof installation.	
7			
8	Re-install upgraded roof insulation using Hempwool to fill void, overboard with Lafarge insulated board to create warm roof, skim, decorate	Re-install upgraded roof insulation using Hempwool to fill void, overboard with Lafarge insulated board to create warm roof, skim, decorate	
	N/A	N/A	
9			
10	Repair, restore. Paint finish	Repair, restore. Paint finish	
	Existing door to be installed as a sliding pocket door, painted	N/A	
11			
12	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.	Remove all blown plaster and render (existing is mixed bonding, sand cement and lime). Spread new 3 coat lime render to fine finish. Insulating lime to external walls.	

	Z	AA	AB
13			
	No. 3 First Floor	No.3 Second Floor	
14	En-suite	Bedroom 5	
13		Carefully lift floorboards and check floor joists.	
	ready for electrician and plumber first fix - support failed joists	· · · · · · · · · · · · · · · · · · ·	
		first fix - support failed joists with	
	bedded into stone walls to support at each end - install 25mm		
	ply screwed to joists at 150c/c, install damp proof system and underfloor heating insulation mat and tile	joists, bedded into stone walls to support at each end - install 25mm ply screwed to joists at	
1,	undernoor heating insulation mat and the	150c/c - relay original pine floors ready for	
16			
17			
10	Shower, Toilet, Basin, Towel Rad		
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28 29			
30			
31			
32			

	Z	AA	AB
33			
34			
35			
36			
37		No.3 Second Floor	
31		1	
38			
39			
40			
41			
42			
43			
.5			
44			

	AC	AD	AE
1			
2			
3			
4			
4 5 6			
6			
7			
1			
8			
9			
10			
11			
12			

	AC	AD	AE
13			
		ı	
14 15			
15			
1.0			
16			
17			
18			
10			
19			
20			
21 22 23			
22			
23			
24			
25			
26 27			
28			
29			
29 30			
31			
32			

	AC	AD	AE
33			
34			
35			
36			
37		I	ı
38			
39			
40			
41			
42			
43			
44			

	AF	AG	АН
1			
2			
3			
4			
4 5 6		I	
6			
7			
1			
8			
9			
10			
11			
12			

	AF	AG	АН
13			
		l	'
14 15			
15			
16			
10			
17			
18			
10			
19			
20			
21 22 23 24 25			
22			
23			
24			
26			
27			
27 28 29			
29			
30			
31			
32			

	AF	AG	АН
33			
34			
35			
36			
37		I	ı
38			
39			
40			
41			
42			
43			
44			

	Al	AJ	AK
1			
2			
3			
4			
4 5 6			
6			
7			
8			
9			
10			
11			
12			

	Al	AJ	AK
13			
		ı	'
14 15			
13			
16			
17			
18			
19			
20			
21			
22			
24			
21 22 23 24 25			
26			
27 28 29			
28			
29			
30			
31			
32			

	Al	AJ	AK
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			

	AL	AM	AN
1			
2			
3			
4			
4 5 6			
6			
7			
8			
9			
10			
10			
11			
12			
12			

	AL	АМ	AN
13			
14 15			
15			
16			
17			
18			
19			
20			
22			
20 21 22 23 24 25			
24			
25			
26			
27			
26 27 28 29 30			
30			
31			
31 32			

	AL	AM	AN
33			
34			
35			
36			
37		I	
38			
39			
40			
41			
42			
43			
44			