



 Weather / rot proofed chassis (glulam / engineered timber) placed on levelling shims (not shown) upon hard surface. No foundation / physical connection to ground beneath.



DAIII515 - WATTS - CARAVAN PLANS



© Copyright - As Dated - Bondstones 1990 Ltd - All Rights Reserved - Enquiries: +44 (0) 1823 210610