




NOTES:

- 1. For PSV, See SD01-013
- 2. Where necessary to match in with existing footway, concrete footway may be laid using the same construction as shown on SD 01-009 for 'All other crossovers'. Infill corners to be wed in block paved areas.
- 3. Manhole's to have grip top applied to match or similar.
- 4. Bedding and pointing may be substituted for proprietary specialist products as directed by Employers Representative.
- 5. Sub—Base depth to be increased, as required by the Employer's Representative, and geotextile membrane laid in poor ground conditions (CBR <2%).
- 6. Design of footways and cycleways to DMRB CD239.






TYPICAL EDGE DETAIL FOR CARRIAGEWAY (see BCC Standard Detail SD01-010)



TYPICAL TIE-IN DETAIL FOR FOOTWAY / VEHICLE CROSSOVER



Footways / vehicle crossover wider than or equal to 2m to be machine laid

