The Conservation Rooflight® Between the Rafter Roof Window Sizes and Prices

Before selecting your size, carefully read the 'Installation Overview' PDF.

PLEASE NOTE: THE DIFFERENCE BETWEEN AN 'ON THE RAFTER' OR 'BETWEEN THE RAFTER' ROOF WINDOW IS IN THE INSTALLATION, NOT THE ROOFLIGHT SIZE, AND DEPENDS ON THE BUILD-UP OF YOUR ROOF.


























Viewable Area
The area of glass
that is viewable
from inside the
room. Please
measure the width
and length at its
closest point to the
glass.













These dimensions are calculated for a roof pitch of 35° and over, should your roof pitch be less than this, please contact us so that we can re-calculate these for you.

Sections for viewable and structural dimensions can be found on our website.

All prices exclude VAT and delivery.


Please note flashing kits and accessories are sold separately.

Egress Conservation Rooflights®

The Conservation Rooflight® On the Rafter Roof Window Sizes and Prices

Before selecting your size, carefully read the 'Installation Overview' PDF.





PLEASE NOTE: THE DIFFERENCE BETWEEN AN 'ON THE RAFTER' OR 'BETWEEN THE RAFTER' ROOF WINDOW IS IN THE INSTALLATION. NOT THE ROOFLIGHT SIZE. AND DEPENDS ON THE BUILD-UP OF YOUR ROOF.
















Structural dimensions

Viewable dimensions

(W) 1021mm x (L) 1180mm
















These dimensions are calculated for a roof pitch of 35° and over, should your roof pitch be less than this, please contact us so that we can re-calculate these for you.

Sections for viewable and structural dimensions can be found on our website. All prices exclude VAT and delivery. Please note flashing kits and accessories are sold separately.

☐ Egress Conservation Rooflights®