


1:100 0mm 1000 2000 3000 4000 5000 1:1 0mm 10 20 30 40 50 Side (South-East) Elevation Scale 1:100


Front (North-East) Elevation Scale 1:100



Rear (South-West) Elevation Scale 1:100



Side (North-West) Elevation Scale 1:100



Asstorm must work to figured dimensions only. All building and site dimensions, levels and sewer invert levels at connection checked on site before work starts. This drawing must be read in conjunction with, and checked against, any structural or little drawings provided. Any discrepancy between issued drawings are to be reported to this practice and verified before we rawing and the building works depicted are the copyright of this practice and may not be reproduced except by written p