

0m Scale Bar @ 1:50

PLANNING

Notes:

> Issued for Planning Approval. Do not use for the purposes of ordering/purchasing.

> Figured dimensions to take precedence over scaling from

drawing. > Drawing to scales as noted. All dimensions in millimetres unless noted otherwise. Check all dimensions and levels on site.

These drawings are subject to Planning and Building Regulation Approval or any other statute in law before construction

 > For details of all structural, mechanical and electrical works where mentioned, refer to relevant specialist's drawings, specification and documentation.

> If any discrepancies are found in the drawings these are to be > If any discrepancies are found in the drawings these are to be brought to the attention of Daintree Design for rectification.
> Boundary lines are indicative only. Exact location of boundaries should be determined on site before work commences.
> Drawing to be printed in colour.

Symbols Key:

+XXXX	Indicates levels on section and elevation
(+XXXX)	Floor to ceiling level (FFL - CL)
+XXXX	Other spot level taken from FFL, e.g. door height
XXXX CH XXXX FC	Window level: suffixed FC = FFL to Cill; CH = Cill to Head; CLH = Ceiling Level to Head.
Falls	Direction of falls for ramps roofs etc.
∠ span	Direction of span for joists
<→UP	Indicates a change in floor level. Arrow always points up from lower to higher level.



