

Head/Sill/Transom

Scale

All dimensions must be checked on site by the contactor before commencing work. All work below ground level is shown provisionally. Inspection of ground condition is essential prior to work commencing. Responsibility for establishing the soil and sub-soil conditions rest with the contractor.

Adjacent Proporties and Boundaries are shown for illustrative purposes only and have not been surveyed unless otherwise stated.

The copyright of this drawing remains with the author and may not be reproduced in any form without prior written consent

revision schedule

```
project
           Alterations to
Hawkley Place,
Hawkley, Liss
title
       Window detail
scale
        1:2 @ A3
date
                            checked
      Apr 2022
                                       ΜA
drawing No.
               A021-010-PL21
revision
                                  artin allman architecture
                   Chartered Architect
                  Southgate Chambers
37/39 Southgate St.
Winchester
                  Hampshire
SO23 9EH
```

t: 01962 866 190 m: 07751 427 813 e: mail@ma-architecture.co.uk www.ma-architecture.co.uk