

General Notes:
The contractor must check and verify the dimensions of the whole site and building, including levels, drainage inverts and locations of all services prior to commencing works.

All dimensions indicated in metric (mm), do not scale.
This drawing is to be read with and checked against any specliaist details, including structural engineers calculations prior to work commencement.

This drawing and the work shown are the copyright of Darryl Bingham and cannot be copied without consent.

www.dbarc.co.uk 07833 934400

Site Location Plan

Styford Hall Northumberland

22-48-01