

All dimensions are to be checked on site.

All dimensions are in millimetres.
All Discrepancies are to be reported to the architect immediately.


Drawings marked "planning" or "design" are not to be used for construction

Drawing is to be read with the schedule of work / specification if applicable





EXISTING SECTION AA SCALE 1:100



EXISTING LEFT SIDE ELEVATION SCALE 1:100

EXISTING SECTION BB SCALE 1:100

