

Linking Rooflights

Externally - They butt right next to each other and are then sealed and flashed over with lead where they join next to each other.



Internally - A support timber of 180mm wide would need to be fitted in between each linked Rooflight.

