

1	Site Office,
	Welfare &
	Assembly Point
	& Car Parking
2	Daily Access for
	Cars & Deliveries
	via Broad
	Marston Road
3	Plant And
	Machinery
	Access from
	Mickleton Road