



TREE PROTECTION LEGEND



TREES, GROUPS OR HEDGES TO BE RETAINED

- 1. TREE CANOPIES HAVE BEEN MEASURED AND PLOTTED AT THEIR CARDINAL POINTS FOR CLARITY AND PRESENTATION PURPOSES.
 2. THE LOCATION AND ATTRIBUTES OF OFF-SITE TREES HAVE BEEN APPROXIMATED UNLESS OTHERWISE STATED.
 3. THE ROOT PROTECTION AREA (RPA) IS A LAYOUT DESIGN TOOL INDICATING THE MINIMUM AREA AROUND A TREE DEEMED TO CONTAIN SUFFICIENT ROOTS AND ROOTING VOLUME TO MAINTAIN THE TREE'S VIABILITY AND WHERE PROTECTION OF THE ROOTS AND SOIL STRUCTURE IS TO BE TREATED AS A PRIORITY. (REFER TO MAIN REPORT FOR FURTHER DETAILS)
 4. SITE TRAFFIC OR OBSTRUCTIONS ENCOUNTERED AT THE TIME OF THE SURVEY MAY HAVE RESULTED IN ARBOREAL FEATURES BEING OMITTED OR THEIR ATTRIBUTES BEING APPROXIMATED.
 5. TREE WORKS ARE TO BE UNDIERTAKEN BY QUALIFIED CONTRACTORS TO BS3998:2010.
 6. TREES ARE TO BE DE RISK ASSESSED FOR NESTING BIRDS AND BATS.
 7. THE ARBORICULTURAL SURVEY IS BASED ON THE SUPPLIED TOPOGRAPHICAL SURVEY. THE LOCATION OF FEATURES SHOWN HAS NOT BEEN CHECKED.
 8. DO NOT SCALE FROM THIS DRAWING.
 9. ALL DIMENSIONS ARE IN CO-ORDINATES UNLESS STATED OTHERWISE.
 10. THIS DRAWING IS TO BE READ IN CONJUNCTION WITH THE ARBORICULTURAL METHOD STATEMENT BY ACS CONSULTING.
 11. THESE DRAWINGS ARE FOR PLANNING PURPOSES ONLY.
 12. TREE PROTECTION FENCING TO BE IN ACCORDANCE WITH BSSSF-2012 TREES IN RELATION TO DESIGN, DEMOLITION AND CONSTRUCTION RECOMMENDATIONS' AND THE ARBORICULTURAL METHOD STATEMENT BY ACS CONSULTING.
 13. TREE PROTECTION RECOMMENDATIONS' AND THE ARBORICULTURAL METHOD STATEMENT BY ACS CONSULTING.
 14. WHERE THE POTENTIAL FOR ENCROACHMENT INTO A TREE'S ROOT PROTECTION RECOMMENDATIONS' AND THE ARBORICULTURAL METHOD STATEMENT BY ACS CONSULTING.
 15. TREE PROTECTION AREA (RPAS) STATEMENT BY ACS CONSULTING.
 16. TREE PROTECTION AREA (RPAS) STATEMENT BY ACS CONSULTING.
 17. THE PROTECTION AREA (RPAS) STATEMENT BY ACS CONSULTING.
 18. TREE PROTECTION AREA (RPAS) STATEMENT BY ACS CONSULTING.
 19. ALL SITE OPERATIVES SHOULD BE MADE AWARE, THROUGH A SITE BRIFFING OR INDUCTION AS TO THE PURPOSE OF THE TREE PROTECTION FENCING, AND OT THE FACT TH

THIS DRAWING SHOULD BE READ IN CONJUNCTION WITH ACS CONSULTING ARBORICULTURAL METHOD STATEMENT



20m

SCALE 1:200