Foundations within RPAs

The use of traditional strip foundations can result in excessive root los and as such should be avoided. Designs for foundations that would minimize the adverse impact upon trees soul include particular attention to the existing levels, proposed finished levels and cross sectional details. Site specific and specialist advice should be sought from the project engineers and arboriculturist.

 Root damage can be minimized by using:
Piles with site investigation used to be determined their optimal location whilst avoiding damage to roots important for the stability of the tree, by means of hand tools or compressed air soil displacement, to a minimum depth of 600mm;
Beams, laid at or above ground level, and cantilevered as peccessing to avoid the proof. necessary to avoid tree roots identified by site investigation

Where a slab for minor structures (e.g. shed base) is to be formed within the RPA, it should bear on the existing ground level, and should not exceed an area greater than 20% of the existing unsurfaced

Slabs for larger structures (e.g. dwellings) should be constructed with a ventilated air space between the underside of the slab and the existing soil surface (to enable gas exchange and venting through the soil surface. In such cases, a specialist irrigation system should be employed (e.g. roof run-off redirected under the slab). The design of the foundation should take into account of the effect on the load bearing properties of the underlying soil from the redirected roof run-off. Approval in principle for a foundation that relies on topsoil retention and authority prior to this approach being relied upon.

Where piling is to be installed near to trees, the smallest practical pile diameter should be used, as this reduces the possibility of striking major tree roots, and reduces the size of the rig required to sink the piles. If a piling mat is required, this should conform to the parameters for ground boarding. Use of the smallest practicle piling rig is also portant where piling within the branch spread is proposed, as this can reduce the need for access facilitation pruning. The pile type should be selected bearing in mind the need to protect the soil and adjacent roots from the potentially toxic effects of uncured concrete, e.g. sleeved bored piles or screw piles.

This information is compliant with British Standard BS5837:2012 Tree in relation to design demolition and construction - Recommendat section 7.5 Special engineering for foundations within the RPA.


Hard Surfacing Removal

Removal of and or replacement of hard surfacing situated either partially or completely within the RPAs of retained trees shall be undertaken with care and under the direct on-site arboricultural undertaken with care and under the direct on-site arboricultural supervision as these areas are likely to contain roots. Where this is necessary the wearing course will be broken up using a hand held pneumatic breaker, hand tools and a wheel barrow to break up and remove the surfacing. If it is necessary to remove the sub base this is to be undertaken using hand tools such as a fork to loosen the material and removed using shovels and wheels barrows. In some situations and at the discretion of the arborist it may be possibly to use an excavator using a hydraulic breaker and suitably sized toothese grading bucket if an excavator is to be used it must be sized toothless grading bucket. If an excavator is to be used it must be


situated outside of the RPAs, on top of the hard surfacing working away from the RPAs or from ground boarding. Which ever system is used the is to be NO disturbance of the soi beneath. If roots are found they are to be roo distribution of the Soli bessian and a layer of either sharp sand, wood chip or top soil to prevent desiccation.

'No Dig' Surfacing

nal confinement system Existing vegetation may be removed with hand tools or sprayed with an approved non residual herbicide such as 'Glyphosate'. The new hard surfacing will be constructed using a 'No Dig' surfacing situated entirely surfacing will be constructed using a 'No Dig' surfacing situated entirely above the existing soil surface and where needed using a proprietary cellular confinement system (GeoWeb or similar) laid over a bi-axel geo-grid (tensar TriAx or similar). Prior to this any small hollows on the surface may be filled with clean sharp sand (not builders sand) to a maximum depth of 150mm. The 'GeoWeb' is to be back filled by hand with a no-fines aggregate of 20mm - 30mm. The area of 'GeoWeb' will be covered with a permeable geotextile fabric and the finished wearing course laid on top. Edge supports of an appropriate size and strength should be set above ground level and secured with haunching or steel pins driven into the ground. the outer edge of the supports may be pins driven into the ground. the outer edge of the supports may be banked up with clean top soil. Road deck system



Raised Slab on mini piles



DO NOT SCALE FROM DRAWING

The original of this drawing was produced in colour - a monochrome copy should not be relied upon.

Root Protection Area (RPA) Notes

BS5837:2012 standard circular RPAs are illustrated here, with consideration required for anticipated root growth influence and restrictions, such as -

Root growth from trees generally may be absent restricted or deflected from site due to the lower/higher level changes, raised concrete structures, existing foundations, hard surfaces, longstanding compacted ground and existing structures for example. Further investigation may be required to establish the presence or absence of roots.

