



Key:

1. The Conservation Rooflight, with Ironmongery Option 1b fixed to structural rafter supports 2 at jamb using coach bolts fitted through fixing rail 1c.
2. Structural rafter support at jamb and structural trimmer support at head and cill 2b.
3. Insulation fitted between structural supports.
4. Timber packers fixed to structural supports 2, 2b to which plasterboard / timber lining is fixed.
5. Plasterboard lining with plasterboard stop 5b to protect the corner. Plasterboard fitted behind the thermoliner of the roof window i.e.
6. Plaster skin.
7. Timber reveal to align with rooflight linings 1d to provide 'frameless' internal appearance. Rooflight linings 1d **MUST BE PAINTED** with a timber finishing paint once the rooflight is installed to ensure longevity of this component. If the linings 1d have been factory painted, they do not require an additional paint finish. Please refer to label attached to roof window frame.
8. Head hardwood tilting fillet.
- 8b. Cill hardwood tilting fillet - to provide minimum 5 degree fall for shedding rain water.
- 9 & 16. Line of general roofing membrane.
10. Softwood battens.
11. Code 3 (consider using code 4 and clipping down roof tiles in severer exposures) lead flashing at head. Carry flashing up the roof and lap UNDER general roofing membrane 9, 16 and UNDER head membrane 15.
- 11b. Code 4 (consider clipping flashing and roof tiles down in severer exposures) lead flashing at cill over tilting fillet 8b. Make the flashing long enough to give triple lap to the tiles below.
12. Roofing tiles.
13. Jamb flashing - lead soakers as shown (or mortar bed).
14. Perimeter silicone seal. Seal perimeter of rooflight 1 JUST PRIOR TO installation of the rooflight using a thick continuous bead of low modulus neutral cure silicone sealant. Ensure sealant to cill 14b is located in a position where it will be covered by the cill flange of the rooflight.
15. Roofing membrane to rooflight head. Dress UNDER general roofing membrane 16, UNDER lead flashing 11 and DRESS general roofing membrane 9 to ensure suitable lap.
17. Vapour barrier.

Please Note:
These sectional details are provided as an installation suggestion. Due to the differing nature of installations we strongly advise you to consult your rooflight installer to verify fitness for purpose. This drawing does not constitute a structural proposal. Sufficiency of structural supports to be checked by rooflight purchaser's structural consultant.

TITLE : <h1>Conservation Rooflight®</h1> <p>> A roof window range suitable for pitched roofs between 17.5° and 65° > Detail applicable ONLY to rooflight models with integral casement timber linings Cold Roof Clay Tile Lead Soakers On the rafter installation detail</p>		DWG NO. : CR_CRCS_LS_C	SHEET NO. : 1 OF 1	REVISION:
SCALE : 1:5 @ A3		DATE : 26/06/2013	This is a suggested installation detail which may not be exactly applicable to all situations and constructors. It is not a detailed or constructional proposal. Installers and designers are advised to check their own details for compliance with all currently applicable Local Authority by-laws, Acts of Parliament and British / ISO standards.	
www.therooflightcompany.co.uk t: 01993 833 108 e: info@therooflightcompany.co.uk		All information contained within this drawing is copyright © and design right of the Rooflight Company. The intellectual property rights of the products detailed within this drawing and embedded 3D models are owned by the Rooflight Company.		