Flood Risk Assessment

To accompany a planning application for an extension to

5 Lammas Road, Watton-at-Stone, Hertford, SG14 3RH

Prepared by

Dr Robin Saunders CEng

Innervision Design Ltd

March 2023



All rights reserved. No part of this report may be reproduced, stored in a retrieval system or transmitted in any form or by any means – electronic, mechanical, photocopying, recording or otherwise – without the prior written permission of Innervision Design Ltd.

Where used to accompany a planning application permission is however granted, in full, to the Local Authority under which the application is made such that the normal processes under all Sections of the Town and Country Planning Act can be implemented.

Contains Environment Agency information © Environment Agency and database right

Contents

Сс	onten	ts		i
Lis	st of F	igures		ii
Lis	st of ⊺	Tables		II
1	Exec	cutive S	Summary	1
2	Intro	oductio	n	2
	2.1	Sitelo	cation	2
	2.2	Develo	opmentdescription	2
	2.3	Sitege	ology	2
3	Polic	cies .		3
	3.1	Standi	ngAdvice	3
	3.2	EA Gu	iidanceonStandingAdvice	3
4	Floo	d risk a	analysis	5
	4.1	Source	esofpotentialflooding	5
		4.1.1	Floodriskfrom seaandrivers	5
		4.1.2	Floodriskfrom groundwater	6
		4.1.3	Floodriskfrom sewerandhighwaydrains	7
		4.1.4	Floodingriskfrom surfacewater	7
		4.1.5	Floodriskfrom infrastructurefailure	8
	4.2	On-site	esurfacewateranalysisandmanagement	9
		4.2.1	GenerationofRun-off	9
		4.2.2	SuDSStatement:	9
		4.2.3	Impactonfloodriskelsewhere	10
5	Leve	els		11
	5.1	Flood	leveldata	11
	5.2	Floorl	eveldata	11
		5.2.1	Assumptionregardingrelativelevels	11
6	Man	ageme	nt of flood risk	12
	6.1	Flood	riskresiliencemeasures	12
	6.2	Flood	mitigationmeasures	14
7	Man	ageme	nt of residual risk	18

De	foron	ces	20
8	Con	clusions	20
	7.3	FloodPlan	19
	7.2	Floodwarningschemes	18
	7.1	Safeaccessandegressroutes	18

Appendix

Α	Emergency flood plan (example)								-		-	-	•		-		-	22	
---	--------------------------------	--	--	--	--	--	--	--	---	--	---	---	---	--	---	--	---	----	--

List of Figures

1	Sitelocationplan	2
2	EA Floodmapping	5
3	EA Historicfloodmapping	6
4	Susceptibilitytogroundwaterflooding	7
5	SW floodriskmapping	8
6	Floodriskfrom reservoirflooding	9
7	Designstrategiesforresistanceandresilience	13
8	UPVC doorsunderfloodconditions	15
9	Floodgateexample	16
10	Sandbagdefence	16
11	Antifloodairbrick	17
12	Airbrickcovers	17
13	AccessandEgressroutes	18

List of Tables

1	SummaryofM aterialSuitability	orBuildingComponents 1	4
---	-------------------------------	------------------------	---

Disclaimer

This document has been prepared solely as a flood risk assessment on behalf of the client. Innervision Design Ltd maintains that all reasonable care and skill have been used in the compilation of this report. However, Innervision Design Ltd shall not be under any liability for loss or damage (including consequential loss) whatsoever or howsoever arising as a result of the use of this report by the client or his agents. If any

un-authorised third party comes into possession of this report they rely on it at their own risk and Innervision Design Ltd owes them no duty, care or skill whatsoever.

1 Executive Summary

- A The extension lies within an existing developed site and this is minor development;
- B The site lies in part within Flood Zone 3, wholly within Zone 2 and at a Low risk from ground water flooding;
- C Flood resilience and mitigation methods will be implemented on site;
- D Safe access/ egress routes are not affected and the site will be signed up to flood warning schemes;
- E There is no documented evidence of flood risk from any other sources;
- F The development does not impact on flood risk elsewhere;
- G Assuming the mitigation, warning and evacuation procedures can be maintained over the lifetime of the development, the proposed minor development to an existing dwelling is considered acceptable.

Client actions required

- I Sign up to flood warning schemes and provide confirmation to the LPA.
- II Complete an emergency flood plan and provide the LPA with an appropriately redacted copy.

Designer actions required

- 1 Ensure plans and specification are updated to incorporate flood resilience and resistance measures prior to submission.
- 2 Ensure plans clearly show FFL of the extension is no lower than the existing FFL.
- 3 Confirm the design intention to manage surface water at source.

2 Introduction

2.1 Site location

The project is at 5 Lammas Road, Watton-at-Stone, Hertord, SG14 3RH (see Figure 1).




Figure 1: Sitelocation plan, as indicated with North topmost. (source: open street map

2.2 Development description

The proposal is for a domestic extension not exceeding $250m^2$ in footprint. The site is an existing developed site and the proposed work is classed as minor development. All plans as submitted under separate cover.

2.3 Site geology

Geological mapping data from within the vicinity indicate Glaciofluvial Deposits, Mid Pleistocene - Sand and gravel, however this would require confirmation on site. If available on site, the superficial deposits will offer medium to high permeability. Infiltration SuDS therefore may be viable (subject to site testing).

3 Policies

In preparation for thisFlood Risk Assessment (FRA), National Planning Policy Framework^[5] and British Standards on Assessing and Managing Flood Risk^[2] were reviewed, and their related policies are, where applicable, referred to in this report.

The Environment Agency has been consulted in order to establish the flood zone of the proposed site.

In addition, planning policies from the Local Authority were also reviewed including its Strategic Flood Risk Assessment.

Some of key policies are summarised as below.

3.1 Standing Advice

Generally the following applies: Apart from habitable basements, domestic extensions within the curtilage of the dwelling (see GDPO definition of, minor development) and non-domestic extensions with a footprint of less than 250 m² will not require a detailed FRA. These applications should demonstrate that the risk of flooding from all sources has been assessed. The main sources of flooding are likely to be tidal, surface water and sewer flooding.

3.2 Environment Agency Guidance on Standing Advice

- You need to provide a plan showing the finished floor levels and the estimated flood levels.
- Make sure that floor levels are either no lower than existing floor levels or 300 millimetres (mm) above the estimated flood level. If your floor levels aren't going to be 300mm above existing flood levels, you need to check with your local planning authority if you also need to take flood resistance and resilience measures.
- State in your assessment all levels in relation to Ordnance Datum (the height above average sea level). You may be able to get this information from the Ordnance Survey. If not, you'll need to get a land survey carried out by a qualified surveyor.
- Your plans need to show how you've made efforts to ensure the development won't be flooded by surface water runoff, eg. by diverting surface water away from the property or by using flood gates.

- If your minor extension is in an area with increased flood risk as a result of multiple minor extensions in the area, you need to include an assessment of the offsite flood risk. Check with your local planning authority if this applies to your development.
- Makesure your flood resistance and resilience plans are in line with the guidance on improving the flood performance of new buildings.

For all relevant vulnerable developments (ie more vulnerable, less vulnerable and water compatible), you must follow the advice for:

- surface water management
- access and evacuation
- floor levels
- extra flood resistance and resilience measures

4 Flood risk analysis

4.1 Sources of potential flooding

Flood risk from various sources at the site is analysed in this section.

4.1.1 Flood risk from sea and rivers

Flooding can occur from these a due to a particularly high tideor surge, or combination of both.

The site is not at risk from tidal flooding.

Flooding can also take place from flows that are not contained within a river channel due to high levels of rainfall in the catchment.

With reference to the Environment Agency Flood Map, Figure 2, the site lies partly in Flood Zone 3 and wholly in Flood Zone 2. This means that the site as a whole has a High probability of fluvial flooding however the dwelling is in Flood Zone 2 and is at a Low risk (between a 1 in 100yr and 1 in 100yr annual probability of fluvial flooding).




Figure 2: Flood mapping from the EA online data. The site falls, in part, within Flood Zone 3 and wholly within Zone 2.

Historic flooding



The site is shown to lie in an area of historic flooding as indicated in Figure 3.

Figure 3: Historic flood mapping from the EA online data. The site falls within an area of historic flooding

4.1.2 Flood risk from groundwater

Groundwater flooding occurs when water levels in the ground rise above surface levels. It is most common in low-lying areas underlain by permeable rock (aquifers), usually due to extended periods of wet weather. The site's geology is classified as having a Medium (>=25%<50%) susceptibility to groundwater flooding.



Figure 4: Susceptibility to ground water flooding. The site falls within an area at medium risk.

Since the proposed development does not involve any basement elements, the impact of groundwater flooding on the proposed site will be minimal. Hence, the risk of groundwater flooding on the proposed site can be considered to be Low.

4.1.3 Flood risk from sewer and highway drains

Flooding occurs when combined, foul or surface water sewers and highway drains are temporarily over-loaded due to excessive rainfall or due to blockage.

There are no indicators to Sewer flooding at the site.

Hence, the risk of sewer and highway flooding to the proposed site can be considered to be Low.

Highway flooding may however manifest as surface water flooding.

4.1.4 Flooding risk from surface water

Flooding occurs when rainfall fall on a surface (on or off the site) which acts as run-off which has not infiltrated into the ground or entered into a drainage system.

With reference to the E.A online mapping, RoFSW, Figure 5, the rear of the site is at risk from surface water flooding.

The adjacent highway is also at a risk from surface water flooding.

The dwelling is however not shown to be at risk from surface water flooding.




Figure 5: SW flood extent mapping.

4.1.5 Flood risk from infrastructure failure

Flooding occurs because of canals, reservoirs, industrial processes, burst water mains or failed pumping stations.

The site is not seen to be at flood risk due to reservoir failure, as shown in Figure 6.



Figure 6: Flood risk from reservoir flooding. The site is not at risk from reservoir flooding (Source: EA flood mapping)

Hence the flood risk to the site from reservoir failure is considered to be negligible.

4.2 On-site surface water analysis and management

4.2.1 Generation of Run-off

The post-development surface water run-off volume will increase when compared to the pre-development level because there is an overall reduction in permeable areas.

Hence all additional surface water arising will require management on site in line with current best practice.

4.2.2 SuDS Statement:

Surface water will be managed in full alignment with the SuDS hierarchy as required under provisions made under the Town and Country Planning Act 1990.

While not required for Planning permission consent it can be confirmed that all SW on site will be also be designed, installed and tested in full accordance with Part H of the Building Regulations 2010 (as amended 2013), Requirement H3, as made under the Building Act 1984.

It is likely that soakaways will be viable given the expected ground conditions associated with the local geology hence the recommendation of this report would be to adopt the use of shallow soakaways and water butts as a viable and proportionate SuDSprovision on site.

4.2.3 Impact on flood risk elsewhere

SW arising: Since the proposal is intending to manage any additional surface water at source the impact on flood risk elsewhere is Low.

Volumetric displacement: The developed area of the site is in Flood Zone 2 hence flood compensation storage volume is not required.

5 Levels

5.1 Flood level data

Not known at time of writing report - conservative assumptions made.

5.2 Floor level data

The proposed floor level to be no lower that any existing ground floor levels.

5.2.1 Assumption regarding relative levels

Without evidence to offer flood levels and relative floor levels, for the purpose of this risk assessment, it is assumed that the existing and hence proposed floor levels are at or below predicted undefended flood levels (rationale: there is no evidence to suggest they are at a higher level than flood levels for undefended Flood Zone 2.

6 Management of flood risk

6.1 Flood risk resilience measures

Becausethesiteislocated in part in Flood Zone3 and wholly in Zone2, and floor levels cannot be raised 300mm above assumed flood levels it is a recommendation of this report that, in line with current best practice^[4], flood risk resilience measures should be incorporated into the development's construction, specifically at ground floor and all construction below such that "the development is appropriately flood resistant and resilient such that, in the event of a flood, it could be quickly brought back into use without significant refurbishment" ^[5].

The Government's guidance states:

The design should be appropriately flood resistant and resilient by:

- using flood resistant materials that have low permeability to at least 600mm above the estimated flood level;
- making sure any doors, windows or other openings are flood resistant to at least 600mm above the estimated flood level;
- using flood resilient materials (for example lime plaster) to at least 600mm above the estimated flood level;
- by raising all sensitive electrical equipment, wiring and sockets to at least 600mm above the estimated flood level;
- making it easy for water to drain away after flooding such as installing a sump and a pump;
- making sure there is access to all spaces to enable drying and cleaning;
- ensuring that soil pipes are protected from back-flow such asby using non-return valves.

In accordancewith thedocument "Improving the Flood Performance of New Buildings - Flood Resilient Construction"^[3] a series of design approaches should be planned to mitigate the flood risk based on the flow chart as at Figure 7.




Figure 7: Design strategies for resistance and resilience^[3]

Table 1 provides guidance on which materials are most suitable, suitable and unsuitable, when considering construction work involved in this project. This report recommends the use of materials from the "most suitable" column were this is at all possible on site, however they are not mandatory requirements.

Component	Most suitable	Suitable	Unsuitable
Flooring	Concrete, pre-cast or in situ	Timber floor, fully sealed, use of marine plywood.	Untreated timber, Chipboard
Floor Covering	Clay tiles, Rubber sheet floors, Vinyl sheet floors	Vinyl tiles, Ceramic tiles	
External Walls - to max flood level	Engineering brick, Reinforced concrete	Low water absorption brick	Large window openings
Doors	Solid panels with waterproof adhesives, Aluminium, plastic or steel	Epoxy sealed doors	Hollow core plywood doors
Internal Partitions	Brick with waterproof mortar, Lime based plasters	Common bricks	Chipboard, Fibreboard panels, Plasterboard, Gypsum plaster
Insulation	Foam or closed cell types	Reflective insulation	Open cell fibres
Windows	Plastic, metal	Epoxy sealed timber with waterproof glues and steel or brass fittings.	Timber with PVA glues and mild steel fittings

Table 1: Summary of Material Suitability for Building Components^[1]

6.2 Flood mitigation measures

The designer is also recommended to consider the provision of a combination of the following flood mitigation measures, to be installed if at all practicable, for use within and around the extension for use in any flooding event:

- Flood resilient doors: Specifically designed to prevent ingress of flood water passive system (see also Figure 8).
- Door defence: Bespoke barriers fitted externally across doors and low windows and/ or the provision of filled sandbags (see also Figures 9 & 10).

- Anti flood air bricks: Where these are unavoidable, these offer replacements for standard air bricks these prevent water entering the sub floor void passive system i.e. fully automatic (see also Figure 11).
- Air brick and flue covers (see also Figure 12).
- No service penetrations or other openings (cat flaps and letter boxes included) below 1m above FFL.



Figure 8: UPVC doors under flood conditions. These appear to offer reasonable flood resilience



Figure 9: Flood gate example.



Figure 10: Sand bag defence.



Figure 11: Anti flood air brick. Example from CSI products



Figure 12: Air brick covers. Example from Buffalo products

7 Management of residual risk

Any residual risk can be afely managed by not impairing accessand evacuation routes, signing residents up to flood warning schemes and preparation of domestic flood plans.

7.1 Safe access and egress routes

The NPPF stipulates that, where required, safe access and escape routes should be available to/ from new developments in flood risk areas. Access routes should be such that occupants can safely access and exit buildings in design period flood conditions. The extension does not impact on existing access and egress routes which are immediately available (ref Figure 13).




Figure 13: Access and Egress routes are existing and not impacted by the extension.

7.2 Flood warning schemes

Since it has been established that the site is sited in an area with a possibility of flooding the owners of the dwelling should (if they have not done so already) sign up to the E.A. "Flood Warnings Direct" which is a free service providing flood warnings by phone,

text or email. See https:///www.ftws.envircenneent+vegeropygrowik/k/ppp/e/bd//dregjister, or call the E.A. on 0345 988 1188 for full information.

7.3 Flood Plan

The project team will also provide the owners of the dwelling with a proforma Flood Plan (See Appendix A for an example). The plan will provide guidance on emergency response procedures in the event of flooding to the site. This will:

- Provide details of who to contact and how;
- Provide details of how to turn off gas, electricity and water mains supplies;
- Provide details of designated safe egress routes out of the building and out of the local area at risk;
- Provide details of E.A. Flood warning codes;
- Provide details of local radio stations
- Provide a check list of essential items.

8 Conclusions

Given that:

- The extension lies within an existing developed site and this is minor development;
- The site lies in part within Flood Zone 3, wholly within Zone 2 and at a Low risk from ground water flooding;
- Flood resilience and mitigation methods will be implemented on site;
- Safe access/egress routes are not affected and the site will be signed up to flood warning schemes;
- There is no documented evidence of flood risk from any other sources;
- The development does not impact on flood risk elsewhere;

and assuming the mitigation, warning and evacuation procedures can be maintained over the lifetime of the development, the proposed minor development to an existing dwelling is considered acceptable.




Dr Robin Saunders CEng, C. Build E, MCABE, BEng(Hons), PhD

Date: 6th March, 2023

References

- [1] J Wingfield; M Bell; P Bowker. Improving the flood resilience of buildings through improved material, methods and details. Technical Report WP2c, CIRA, 2005.
- [2] BSI. BS 8533:2011. Technical report, 2011.
- [3] CIRIA, CLG, EA and DEFRA. Improving the flood performance of new buildings. Flood resilient construction, 2007.

- [4] D Kelly, M Barker, JLamond, SMcKeown, E Blundell, and E Suttie. Code of practice for property flood resilience. Technical report, CIRIA, 2020.
- [5] Ministry of Housing, Communities and Local Government. National planning policy framework. 2021.



A Emergency flood plan (example)

Revironment Agency	Identify what you would need to take with you if you had to leave your home Understand the flood warning codes																			Be prepared for flooding. Act now
	Find out where you can get sandbags Identify who can help you/ who you can help	Location																		Be prep
What can I do NOW?	he best way of stopping er entering your property lood plan and prepare a		ifety	ags in place	way from the risk	es		ang curtains over rods		bags and move to safety			them down		and stock		safety	s ay need to leave your home	Get your flood kit together and include a torch, warm and waterproof clothing, water, food, medication, toys for children and pets, rubber gloves and wellingtons	protection products on the market to help you protect lamage. A directory of these is available from the www.bluepages.org.uk
Personal flood plan	Put important documents out of Look at t flood risk and protect in Make at polythene Make at Check your insurance covers you flood kit for flooding What can you do if a flood is expected in your area?	Actions	Home Move furniture and electrical items to safety	e Put flood boards, polythene and sandbags in place	Make a list now of what you can move away from the risk	a Turn off electricity, water and gas supplies	G Roll up carpets and rugs	 Unless you have time to remove them hang curtains over rods 	G Move sentimental items to safety	e Put important documents in polythene bags and move to safety	Garden and outside	G Move your car out of the flood risk area	G Move any large or loose items or weigh them down	Business	 Move important documents, computers and stock 	 Alert staff and request their help 	G Farmers move animals and livestock to safety	Evacuation - Prepare a flood kit in advance c Inform your family or friends that you may need to leave your home	 Get your flood kit together and include a torch, warm and waterproof clothing, water, food, medication, toys for children and pets, rubber gloves and welling 	There are a range of flood protection products on the market to help you pr your property from flood damage. A directory of these is available from the National Rood Forum at www.bluepages.org.uk

GEHO0709BOPU-E-E