

LATH

SAVOLIT

	depth from sole plate to brick plinth	depth from wall plate to eave board	depth from wall plate to verge board	depth from timber studs to sole plate and wall plate	depth of window drip groove to timber studs	batten	savolit	lime render	total render depth	difference between window drip groove and Savolit render finish	batten	lath	lime render	total render depth	difference between window drip groove and lath render finish
East elevation window	1 30	65	85	25	40	25	15	10	50	0	25	7	15	47	3
	2 30	65	85	25	40	25	15	10	50	0	25	7	15	47	3
	3 30	65	85	25	50	25	15	10	50	30	25	7	15	47	33
	4 30	65	85	25	60	25	15	10	50	40	25	7	15	47	43
	5 30	65	85	25	30	25	15	10	50	5	25	7	15	47	8
	6 30	65	85	25	40	25	15	10	50	5	25	7	15	47	8
	7 30	65	85	25	50	25	15	10	50	20	25	7	15	47	23
	8 30	65	85	25	55	25	15	10	50	15	25	7	15	47	18
North elevation window	1 15	65	85	25	65	25	25	10	60	25	25	7	15	47	38
	2 15	65	85	25	50	25	25	10	60	0	25	7	15	47	13
	3 15	65	85	25	50	25	25	10	60	20	25	7	15	47	33
	4 15	65	85	25	50	25	25	10	60	15	25	7	15	47	28
West elevation window	1 25	65	85	25	35	25	15	10	50	0	25	7	15	47	3
	2 25	65	85	25	40	25	15	10	50	5	25	7	15	47	8
	3 25	65	85	25	40	25	15	10	50	5	25	7	15	47	8
	4 25	65	85	25	35	25	15	10	50	30	25	7	15	47	33
	5 25	65	85	25	60	25	15	10	50	20	25	7	15	47	23
	6 25	65	85	25	40	25	15	10	50	20	25	7	15	47	23
	7 25	65	85	25	40	25	15	10	50	0	25	7	15	47	3
	8 25	65	85	25	40	25	15	10	50	0	25	7	15	47	3
	9 25	65	85	25	40	25	15	10	50	0	25	7	15	47	3
	10 25	65	85	25	40	25	15	10	50	0	25	7	15	47	3
South elevation window	1 25	65	85	25	30	25	15	10	50	20	25	7	15	47	23