


REMOVE GW04 & BRICKWORK BELOW OPENING DOWN TO FFL

FORM NEW GLAZED SINGLE DOORWAY



Installation of timber doors - Guidance Notes

Allow for a 10mm tolerance overall (5mm each side)
Before any fixings are used the window should be packed all four sides
level and plum in the opening. When building-in a continuous support
at cill level can be provided by a mortar bed.
Cill and head packing should be a maximum 150mm from each jamb
and beneath each mullion

and beneath each mullion.
Side fixings should be used at 150mm from the top and bottom of the frame, and a maximum 450mm between fixings.
Fix into the brickwork using either a screw and anchor plug

(8 x 120mm fixing recommended) or self tapping concrete anchor, ensure the fixing is at least 25mm into the brickwork, preferably 50mm. Both the frame and the brickwork will need to be drilled creating a pilot hole to fix into.

Fix the window through the frame, where possible using unobstructive locations. The fixings must be at the same point as the spacer to ensure the fame does not become distorted.

To prevent air infiltration between the door and the adjacent wall the


gap should be sealed using an expanding foam seal. An additional seal can then be provided by a silicone based sealant.


EXTERNAL FINISH TO BE STAINED TO MATCH EXISTING WINDOWS & DOORS

REMOVE GW01 & GW02 & BRICKWORK BELOW OPENING DOWN TO FFL


FORM NEW GLAZED SINGLE DOORWAYS

DOOR ELEVATIONS 1:10 @ A1






TYPICAL DOOR HEAD & CILL DETAIL



TYPICAL JAMB DETAILS



DOOR JOINERY DETAILS 1:5 @ A1

DO NOT SCALE THIS DOCUMENT - USE FIGURED DIMENSIONS ONLY

ALL DIMENSIONS MUST BE CHECKED ON SITE PRIOR TO
COMMENCEMENT OF ANY RELATED WORKS.

THIS DOCUMENT IS COPYRIGHT OF THE ORIGINATOR, IT MUST NOT
BE ALTERED, REPRODUCED OR DISTRIBUTED WITHOUT PRIOR
CONSENT.

THIS DOCUMENT MUST BE READ IN CONJUNCTION WITH ALL
SUPPORTING DOCUMENTS PRODUCED BY THE ORIGINATOR AND
OTHER PROJECT DISCIPLINES.

OS MAPPING OBTAINED FROM PROMAP LICENCE No. 1000022432
REPRODUCED BY BERRYS UNDER OS LICENCE No. 100003668



SCALE BAR & NORTH POINT:

DISCLAIMER NOTES:




**Chartered Practice** 

BEECH HOUSE
SHREWSBURY BUSINESS PARK
SHREWSBURY
SHROPSHIRE
SY2 6FG
ORIGINATING OFFICE:

TEL: 01743 2
shrewsbury@berrys.u

PLEASE REFER TO TOPOGRAPHICAL SURVEY DRAWING DRAWING No. SA47064\_BRY\_ST\_PL\_C\_0002 FOR FURTHER DETAILS AROUND GROUND FLOOR PLAN



## BERRYS

PLANNING

CLIENT:

CHRIS PATEMAN

PROJECT: 4 FRODESLEY HALL FARM BARNS
FRODESLEY, SHREWSBURY,
SHROPSHIRE SY5 7GA

DRAWING:

PROPOSED JOINERY DETAILS

SCALE @ A1: DRAWN BY: CHKD BY: DATE:
1:10 & 1:5 OH LF 10.08.2

DRAWING No: REVISIO

DRAWING No: REVISI
SA45974 -BRY-XX -DT - A - 01 \_