



GUIDE TO INTERPRETING MAINS RECORDS PLAN



Inveralmond House, 200 Dunkeld Road, Perth PH1 3AQ 🕑 ssen.co.uk

Scottish and Southern Electricity Networks is a trading name of: Scottish and Southern Energy Power Distribution Limited Registered in Scotland No. SC213459; Scottish Hydro Electric Transmission plc Registered in Scotland No. SC213461; Scottish Hydro Electric Power Distribution plc Registered in Scotland No. SC213460; (all having their Registered Offices at Inveralmond House 200 Dunkeld Road Perth PH1 3AQ); and Southern Electric Power Distribution plc Registered in England & Wales No. 04094290 having their Registered Office at No. 1 Forbury Place 43 Forbury Road Reading RG1 3JH which are members of the SSE Group <u>www.ssen.co.uk</u>





INTRODUCTION

The Health & Safety Executive have produced a document entitled 'Avoiding danger from underground services'. Copies are available from HMSO's accredited agents and good booksellers, Ref HS(G)47, ISBN 0118854925.

WHEN WORKING IN THE VICINITY OF ELECTRICITY CABLES AND OVERHEAD LINES PLEASE FOLOW THE DO'S & DON'T'S LISTED BELOW.

<u>DO'S</u>

- **Do** Make sure that you have plans of the cables in the area before any excavation work starts. Remember that some cables such as service cables may not be shown on the plans. Cables owned by other companies are not shown, e.g. local authorities, Department of the Environment, National Grid Co. etc.
- **Do** Make sure that you understand the plans that have been supplied to you. For detailed explanation of the symbols used by Scottish & Southern Electricity Networks Distribution (SSEN Distribution) refer to this guide & the key shown on the plan
- **Do** Use a cable avoidance tool (CAT) to determine the position of the existing cables in the work area. The positions should be clearly marked, and further tests made as work proceeds. **If in doubt, get advice from your supervisor.**
- **Do** Hand dig trial holes over the indicated route of the cable, excavate alongside.
- **Do** Ask for a cable to be made dead if it is buried in concrete. Please not that this is likely to be a costly process.
- **Do** Watch for signs of cables as work progresses, such as marker tapes or cable covers which may be exposed.
- **Do** Backfill carefully using stone free soil around cables, replacing marker tapes and covers.





- **Do** Ensure that there is maximum clearance above all cable & joints.
- **Do** Notify SSEN Distribution immediately should accidental damage to cables occur however large or small. Arrange to keep people well clear of the cable that has been damaged. Do not backfill an area where cable damage has occurred.

DON'T'S

- **Don't** Operate a bulldozer, scraper, dragline or excavator unless you are satisfied that there are no buried cables or overhead lines in the working area.
- **Don't** Use picks, forks or pointed instruments in soft clay or soil where cables are present, exercise extreme caution where such instruments are used to free lumps of stone or to break up firmly compacted ground.
- **Don't** Use exposed cables as a convenient step or handhold.
- **Don't** Handle or attempt to alter the position of any cable.

REMEMBER THAT A DAMAGED CABLE MAY CAUSE EXTENSIVE LOSS OF SUPPLIES, MAKE EXPENSIVE REPAIRS NECESSARY AND CAUSE SERIOUS OR EVEN FATAL INJURY.


IF IN DOUBT ASK SSEN DISTRIBUTION





UNDERSTANDING THE INFORMATION ON THE PLANS.

AVERAGE DEPTH OF CABLES: Footpaths 0.6 metres Road Crossings 0.75metres NB These depths are only approximate, depths may vary. It should also be noted that surface levels can change subsequent to the cables being laid.



Mains records symbols definitions and examples:

Overhead lines & Poles – These are depicted as follows:

- 1. Overhead Line These can be either High Voltage or Low Voltage, colour denotes voltage.
- 2. Poles.
- 3. Pole Mounted Transformer.







B. Typical example of Low Voltage cable records:

- 1. Sub Station
- 2. Low Voltage Underground cable.
- 3. Link Boxes: This is a box with a manhole cover marked as belonging to SSEN Distribution containing links. Either two or four cables will lead away from a link box.
- 4. Straight Joint: This is where two separate cables are joined together.
- 5. Breech Joint: This is where another cable is attached to the main.
- 6. Pot End: This is the end of the cable. In certain circumstances service cables to properties can be taken from the pot end. These services may not be shown on the plans.
- 7. Road crossing duct where a cable is routed under a path or road.
- 8. Cable terminations/Pole Box: Where underground cables are connected to overhead lines
- 9. Overhead line.
- 10. Street Lamps.





 Services to properties: The service cable to an individual property are not always shown on the mains records that SSEN Distribution supply. In some cases, a service can be looped from an adjacent property.

C) Typical example of High Voltage cable record.



- 1. Sub Station
- 2. High Voltage Underground cable Colour denotes voltage.
- 3. Straight Joint: This is where two separate cables are joined together.
- 4. Breech Joint: This is where another cable is attached to the main.
- 5. Cable terminations/Pole Box: Where underground cables are connected to overhead lines
- 6. Overhead Switch.





SSEN DISTRIBUTION ELECTRIC SYMBOLS

		1
Service cable	 Single Poles	
LV Mains	 H Poles	
LV Mains and Services (Split Phase)	 3 Poles	
2-3.3kV	 Tower	
6.6kV	 Pole Mounted Transformer	11kV
11kV	 Circuit Breaker	
22kV	 Switch Disconnector/ OH Air Break	Ó
33kV	 Pole Box	
66kV	 Straight Joint	
132kV	 Mains Breech Joint (Tee)	•
Fibre Optic	 Service Breech Joint	
Pilot Cable	 Trifurcating Joint	
Assumed Route	 Pot End	P∕E
Out of Service	 Capped End	CVE
Ducting	 Sealing End	





Service Connector Joint	•	Surge Diverters	W
Overhead Connector	(Pillar	
Wall Box Joint	¥	Substation	
Flying Stay	FS	Non Electrical Item	•
Stay		Street Furniture	
PME Earth		LV Link Box	-
Neutral Earth	·ı⊨●	LV Supply Point	-
Pit		ASLs	
Other Network		Embedded Network	